User Guide

■ Notice

The illustrations in this user's manual are for reference only. Actual product specifications may vary with territories.

The information in this user's manual is subject to change without notice.

THE MANUFACTURER OR RESELLER SHALL NOT BE LIABLE FOR ERRORS OR OMISSIONS CONTAINED IN THIS MANUAL AND SHALL NOT BE LIABLE FOR ANY CONSEQUENTIAL DAMAGES, WHICH MAY RESULT FROM THE PERFORMANCE OR USE OF THIS MANUAL.

The information in this user's manual is protected by copyright laws. No part of this manual may be photocopied or reproduced in any form without prior written authorization from the copyright owners.

Product names mentioned herein may be trademarks and/or registered trademarks of their respective owners/companies.

The software described in this manual is delivered under a license agreement. The software may be used or copied only in accordance with the terms of the agreement.

This product incorporates copyright protection technology that is protected by U.S. patents and other intellectual property rights.

Reverse engineering or disassembly is prohibited.

TABLE OF CONTENTS

Notice 2

Preface 5

- 1.1 Regulations Information 5
- 1.2 Safety Instructions.....7
- 1.3 Notes for this Manual 8
- 1.4 Release History.....9

Getting to know the basics 10

- 2.1 Product Specification 10
- 2.2 Preparing your Computer.....13
- 2.3 Product Overview.....14
  - 2.3.1 Top-Open View 14
  - 2.3.2 Bottom Side View.....16
  - 2.3.3 Right Side View.....17
  - 2.3.4 Left Side View 18
  - 2.3.5 Front Side View.....19

Getting Started 20

- 3.1 AC Adapter.....20
- 3.2 Installing the battery pack 21
- 3.3 Knowing the Keyboard.....23
  - 3.3.1 Windows 7/ XP for keyboard users 24
  - 3.3.2 Windows 8 for keyboard users.....26

■ 3.4 Using the touchpad 28
■ 3.4.1 Windows 7/ XP Touchpad Usage 29
■ 3.4.2 Windows 8 Touchpad Usage 32
BIOS SETUP 34
■ 4.1 About BIOS Setup.....34
■ 4.1.1 When to Use BIOS Setup ?.....34
■ 4.1.2 How to Run BIOS Setup ?.....34
■ 4.2 BIOS Setup Menu 35
■ 4.2.1 Info Menu 36
■ 4.2.2 Main Menu.....37
■ 4.2.3 Advanced Menu 39
■ 4.2.4 Security Menu 40
■ 4.2.5 Boot Menu.....42
■ 4.2.6 Exit Menu 43

■ 1.1 Regulations Information

• FCC-B Radio Frequency Interference Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the authority to operate equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

• Reorient or relocate the receiving antenna.

• Increase the separation between the equipment and receiver.

• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

• Consult the dealer or an experienced radio/TV technician for help.

CAUTION: Any changes or modifications not expressly approved by the guarantee of this device could void the user's authority to operate the equipment.

• CE compliance

This device is classed as a technical information equipment (ITE) in class B and is intended for use in living room and office. The CE-mark approves the conformity by the EU-guidelines:

- EMV-guideline 89/336/EWG electromagnetic tolerance

- LVD-guideline 73/23/EWG use of electric devices within certain voltage-limits

■ 1.2 Safety Instructions

The following safety precautions will increase the life of the Computer. Follow all Precautions and instructions.



Do not place this device underneath heavy loads or in an unstable position.

Do not use or expose this device around magnetic fields as magnetic interference may affect the performance of the device.



Do not expose this device to high levels of direct sunlight, high-humidity or wet conditions.

Do not block the air vents to this device or impede the airflow in any way.

Do NOT expose to or use near liquid, rain, or moisture.

Do NOT use the modem during electrical storms.

•The unit can be operated at an ambient temperature of max. 35°C (95°F). Do not subject it to temperatures below 5°C (41°F) or above 35°C (95°F).

•CAUTION: RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

■ 1.3 Notes for this Manual

CAUTION! Important information that must be followed for safe operation.

NOTE : Information for special situations.

■ 1.4 Release History

Version	Revision Note	Date
1.0	First Released	10.2012

Getting to know the basics

■ 2.1 Product Specification

This User's Manual provides instructions and illustrations on how to operate this notebook. It is recommended to read this manual carefully before using this notebook.

• Physical Characteristic

Dimension	14": 343.57 × 236.6 × 34.5 mm (w/o rubber foot) 15.6": 382 × 255 × 35.9 mm (w/o rubber foot)
Weight	14": 1.91kg w/4cells ; 2.0kg w/6cells 15.6": 2.63kg w/4cells ; 2.73kg w/6cells (depend upon the actually shipping product)

• CPU

Support Processor (Optional)	Intel® Chief River Ivy Bridge Intel® Huron River Sandy Bridge

• Core Chips

Express Chipset (Optional)	Intel® HM76 / Intel® HM75 / Intel® HM70

• Memory

DDRIII	DDR3 1066/1333 MHz, RAM socket x2

• Power

AC Adapter	65 Watts, 2 Pin
Battery	Li-ion Battery

· Storage

HDD	2.5” SATA HDD support
Card reader	4 in 1 Card Reader Card

· Optical Device

ODD	12.7mm SATA ODD support

· I/O Port

DC-in	x 1	
USB (Optional)	USB2.0 x 2 + USB3.0 x 1 or USB2.0 x 3	
CRT	x 1	
RJ45	x 1	
Phone jacks for	x 2	(microphone/ headphone)
Card Reader	x 1	(SD/MS/MMC/MS pro)
HDMI	x 1	

· Audio

Audio Codec	Azalia standard support, D3 mode support
Speaker/MIC	Build-in 2 speakers and internal MIC support

· Input

Keyboard	Standard NB KB
Pointing Device	PS2 Touch Pad with 2 buttons

· Display

VGA (Optional)	Integrated Graphic or Integrated HD Graphic
LCD	14.0" HD, 16:9 LED type, resolution 1366 x 768
	15.6" HD, 16:9 LED type, resolution 1366 x 768

· Communication Port

LAN	10/100/1000 Mb/Sec
Wireless LAN	IEEE802.11b/g/n support
Bluetooth (Optional)	BT 3.0 & 4.0, USB interface support

· Webcam

Webcam or HD webcam (Optional)	Build-in Webcam module

CAUTION : MODEL IS DESIGNED TO USE WITH THE FOLLOWING AC ADAPTER MODEL ONLY.

Manufacture: APD
Model: DA-65A19

Manufacture: Delta
Model: ADP-65JH AB

■ 2.2 Preparing your Computer



1. Turn your notebook computer upside down so the bottom is facing up.

   Insert the battery pack as shown into the battery compartment until it clicks into place. Then slide the lock/unlock latches into the lock position.

2. Plug the AC adapter cable into the DC power connector.

3. To open your notebook computer.

4. Press the power button to turn on your notebook computer.

2.3 Product Overview

This section provides the description of basic aspects of the notebook.

NOTE: The product's color, I/O port, indicator location, and specification will depend upon the actually shipping product.

2.3.1 Top-Open View

The figure of top-open view and description shown below will lead you to browse the main operating area of your notebook.



CAUTION: When you are not using the computer, keep the LCD screen closed to protect it from dust.

Top Side Components	Function Description
1 Webcam (Optional)	The built-in Webcam allows picture taking or video recording.
2 LCD screen	Displays of your notebook computer.
3 Power Button	Turns on the power of your notebook computer.
4 Keyboard	The keyboard provides keys with comfortable travel.
5 Touchpad	Touch-sensitive pointing device which functions like the mouse.
6 Left and right touchpad buttons	The left and right buttons function like the left and right buttons on a standard mouse.
7 Power Status LED	The Power indicator shows the Power status.
7 Wireless Status LED	The Wireless indicator shows the Wireless status.
7 Battery Status LED	The Battery indicator shows the Battery status.
7 HDD Status LED	The HDD indicator shows the HDD status.
8 Microphone	Built-in microphone.
9 Internet Quick Launch Button (Optional)	The key provides quick launch internet.
10 Multi-Media Quick Launch Button (Optional)	The key provides quick launch media player.

■ 2.3.2 Bottom Side View

Refer to the following illustration to identify the components on this side of the computer.

NOTE : The product's thermal vent will depend upon the actually shipping product.



Top Side Components		Function Description
1	4-in-1 Card Reader	SD/MMC/MS/MS Pro Memory Card.
2	Battery lock latch	Slide to lock / unlock the battery (--→ Battery Release).
3	Battery pack	Insert the battery into this compartment.

CAUTION: Do not put the computer on your LAP or other Parts of the body to avoid injury from the heat.

■ 2.3.3 Right Side View

Refer to the following illustration to identify the components on this side of the computer.



Top Side Components		Function Description
1 Headphone jack		Connects amplified speakers or headphones into this jack.
2 Microphone jack		Connects a microphone into this jack.
3 USB Ports		Connects an USB device. (such as USB Zip drive, keyboard or mouse) into this jack.
4 Optical drive		Slot for inserting a disc.
5 Eject button		Ejects the CD/DVD disc.

■ 2.3.4 Left Side View

Refer to the following illustration to identify the components on this side of the computer.



Top Side Components		Function Description
1 Power Connector	⎓	Connects the AC adapter into this connector.
2 HDMI Port	HDMI	Connects an external monitor.
3 Network Jack		Connects network.
4 External monitor connector		Connects an external monitor.
5 USB Port		Connects an USB device (such as USB Zip drive, keyboard or mouse) into this jack. -Intelligent charging for external USB device in power off mode. (Press power button in 5secs when power off, than the USB LED indicator is brightness, the charging function is enable. Press power button in 1sec, it can be disable the charging function.) -Enhance USB power from 500mA to 1.5A
6 Vent		Thermal Vent.

2.3.5 Front Side View

Refer to the following illustration to identify the components on this side of the computer.



Top Side Components	Function Description
1 Stereo speakers	Produce stereo sound.
2 4-in-1 Card Reader	SD/MMC/MS/MS Pro Memory Card.

3.1 AC Adapter

Please be noted that it is strongly recommended to connect the AC adapter and use the AC power while using this notebook for the first time. When the AC adapter is connected, the battery is being charged immediately.

Note that the AC adapter included in the package is approved for your notebook; using other adapter model may damage either the notebook or other devices attached to it.



CAUTION: Do not use inferior extension cords as this may result in damage to your notebook. The notebook comes with its own AC adapter. Do not use a different adapter to power the computer and other electrical devices.

NOTE: The power adapter may become warm to hot when in use. Be sure not to cover the adapter and keep it away from your body.

■ 3.2 Installing the battery pack

Insert the battery pack as shown into the battery compartment until it clicks into place. Then slide the lock / unlock latches into the lock position.

Unlock





Lock





NOTE: Never attempt to remove the battery pack while the computer is turned ON, as this may result in the loss of working data.

CAUTION! Only use batteries that are approved by an authorized dealer. All batteries are not the same and therefore should not be treated as such. Using the wrong battery could cause serious damage to your computer and yourself through toxic emissions.

CAUTION! Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions. Never remove the battery pack while the power is on as this may result in data loss when the system loses power.

■ 3.3 Knowing the Keyboard

The following defines the colored hot keys on the Keyboard.

The colored commands can only be accessed by first pressing and holding the function key while pressing a key with a colored command.

• Keyboard for Windows 7/XP :



• Keyboard for Windows 8 :



NOTE: The keyboard differs for each territory.

■ 3.3.1 Windows 7/ XP for keyboard users

To activate these functions, press and hold down <Fn> together with the keys described below:

■ Function Keys

Keypad		Function Description	
Fn	Esc	BT on/off: (Optional)	Press this key combination (Fn+Esc) to enter BTon/off mode.

"When users would like to upgrade BT2.1 to BT3.0, please power on Fn+F4 WiFi function first, but cannot connect to WLAN AP (WLAN Access Points). Only WLAN module RTL8188CE could support BT3.0 feature. BT3.0 will advance OPP, FTP & PAN profile throughput performance."

Fn +	F1	Suspend:	Press this key combination (Fn+F1) to enter sleep mode.
Fn +	F2	Power Saving:	Press this key combination (Fn+F2) to enter power saving mode (CPU will keep the lowest speed).
Fn +	F3	LCD/CRT/ HDMI mode:	Press this key combination (Fn+F3) to enter LCD/CRT/HDMI mode. Changes Display Mode: LCD only, LCD+ CRT, CRT only, HDMI+CRT, HDMI only, LCD+HDMI simultaneously.
Fn +	F4	WLAN on/off:	Press this key combination (Fn+F4) to enter WLAN on/off mode.

"When users disable WLAN function, WLAN device will be removed from Windows Device Manager or not is depending on WLAN module itself power design."

■ Function Keys

Keypad		Function Description
	OSD: (on screen display):	Press this key combination (Fn+F5) to show a OSD bar for knowing the definition of function keys.
	Touch pad:	Press this key combination (Fn+F6) to enter Touch pad mode.
	Webcam on/off:	Press this key combination (Fn+F7) to enter Webcam on/off mode.
	MUTE:	Press this key combination (Fn+F8) to enter MUTE mode.
	Volume down:	Press this key combination (Fn+F9) to enter Volume down mode.
	Volume up:	Press this key combination (Fn+F10) to enter Volume up mode.
	Brightness down:	Press this key combination (Fn+F11) to decrease brightness of LCD display.
	Brightness up:	Press this key combination (Fn+F12) to increase brightness of LCD display.

■ 3.3.2 Windows 8 for keyboard users

To activate these functions, press and hold down <Fn> together with the keys described below:

■ Function Keys

Keypad	Function Description	
	Suspend:	Press this key combination (Fn+F1) to enter sleep mode.
	Power Saving:	Press this key combination (Fn+F2) to enter power saving mode (CPU will keep the lowest speed).
	LCD/CRT/ HDMI mode:	Press this key combination (Fn+F3) to enter LCD/CRT/HDMI mode. Changes Display Mode: LCD only, LCD+ CRT, CRT only, HDMI+CRT, HDMI only, LCD+HDMI simultaneously.
	RADIO on/off:	Press this key combination (Fn+F4) to turn all radios on or off.

Annotation: FN+F4 is combo key for Bluetooth and WIFI function on/off.
OSD instruction will show WIFI icon only.

	OSD: (on screen display):	Press this key combination (Fn+F5) to show a OSD bar for knowing the definition of function keys.

■ Function Keys

Keypad		Function Description
	Touch pad:	Press this key combination (Fn+F6) to enter Touch pad mode.
	Webcam on/off:	Press this key combination (Fn+F7) to enter Webcam on/off mode.
	MUTE:	Press this key combination (Fn+F8) to enter MUTE mode.
	Volume down:	Press this key combination (Fn+F9) to enter Volume down mode.
	Volume up:	Press this key combination (Fn+F10) to enter Volume up mode.
	Brightness down:	Press this key combination (Fn+F11) to decrease brightness of LCD display.
	Brightness up:	Press this key combination (Fn+F12) to increase brightness of LCD display.

3.4 Using the touchpad

The touchpad is a rectangular electronic panel located just below your keyboard. You can use the static-sensitive panel of the touchpad and slide it to move the cursor. You can use the buttons below the touchpad as left and right mouse buttons.

Press the left ❶ and right ❷ buttons located on the edge of the touchpad to make selections and run functions. These two buttons are similar to the left and right buttons on a mouse. Tapping on the touchpad produces similar results.



CAUTION: Keep your fingers dry and clean while using the touchpad. Also keep the touchpad dry and clean. The touchpad is sensitive to finger movements. Therefore, the lighter the touch, the better theresponse. Tapping too hard will not increase the touchpad's responsiveness.

■ 3.4.1 Windows 7/ XP Touchpad Usage

■ Multi-finger gesture input

Finger gesture	Function Description		
Zooming In/Out	 Zooming In		 Zooming Out
Rotation	 Rotating Left		Rotating Right
Scroll Up	 On-pad Scroll	or	 Two-finger Up
Scroll Down	 On-pad Scroll	or	 Two-finger Down
Scroll Left/Right	 Two-finger Left		 Two-finger Right

Finger gesture	Function Description
Play Slide Show	 Three-finger Up
End Slide Show	 Three-finger Down
Page Up	 Three-finger Left
Page Down	 Three-finger Right

If users do not install Touchpad gesture driver, then they could follow below finger gesture to execute Touchpad scrolling up and down function.

Finger gesture	Function Description
Scroll Up	 On-pad Scroll or  One-finger Up or  Two-finger Up
Scroll Down	 On-pad Scroll or  One-finger Down or  Two-finger Down

■ 3.4.2 Windows 8 Touchpad Usage

■ Win8 Touch Pad Gesture

Modern touchpad gesture:
A Windows 8 modern touchpad should support the core touch gestures described in the following table.

Finger gesture		Function Description
Single-finger Slides		Mouse cursor manipulation
Single/two-finger tap, double tap		Primary button click, double click at cursor location
Two-finger Slides		Horizontal or vertical scroll (mouse wheel)
Two-finger Pinch		Zoom (Ctrl + mouse wheel)

Finger gesture		Function Description
Swipe in from the right edge		Toggle the charms (+ C)
Swipe down from the top edge		Toggle the app commands (+ Z)
Swipe in from the left edge		Switch to last application (+ Ctrl + Backspace)

BIOS SETUP

4.1 About BIOS Setup

4.1.1 When to Use BIOS Setup ?

You may need to run the BIOS Setup when:

- An error message appears on the screen during the system booting up and is requested to run SETUP.
- You want to change the default settings for customized features.
- You want to reload the default BIOS settings.

4.1.2 How to Run BIOS Setup ?

To run the BIOS Setup Utility, turn on the notebook and press the [Del] key during the POST procedure.

If the message disappears before you respond and you still wish to enter Setup, either restart the system by turning it OFF and ON, or simultaneously pressing [Ctrl]+[Alt]+[Del] keys to restart.

Be noted that the screen snaps and setting options in this chapter are for your references only.The actual setting screens and options on your Notebook may be different because of BIOS update.

The setup function only can be invoked by pressing [Del] or [F2] key during POST that provide a approach to change some setting and configuration the user prefer, and the changed values will save in the NVRAM and will take effect after the system rebooted. The setup uses a menu interface to allow the user to configure their system and the features are briefly listed as follow.

Press [F7] key for Boot Menu.

NOTE : The drivers, BIOS and utilities bundled in the support DVD may vary by models and are subject to change without notice.

■ 4.2 BIOS Setup Menu

Once you enter the BIOS Setup Utility, the Main Menu will appear on the screen. Select the tags to enter the other menus.

Info Menu

Show System Information about BIOS version,CPU features and Manufacturer.

Main Menu

Show system overview about memory size, main HDD or ODD and setting of system time and date.

Advanced Menu

To select the XD feature enable or disable XD feature only work with Intel platform + Windows.

Security Menu

Install or clear the password settings for supervisor and user.

Boot Menu

Configure Settings during System Boot.

EXIT Menu

Save or discard the changes before leaving the BIOS Setup Menu.

■ 4.2.1 Info Menu


Aptio Setup Utility – Copyright (C) 2011 American Megatrends, Inc.
Info Main Advanced Security Boot Exit
System Information
BIOS Information
BIOS Version A.01
EC Version 0.10.01
Build Date 03/27/2012
Processor
Processor Type Genuine Intel(R) CPU @ 1.70GHz
Processor Speed 1700 MHz
BIOS Information
Manufacturer Name Standard
Product Name Standard
Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.

- System Information

  This item provides the information about the firmware, processor, and system memory.

- BIOS Information

  BIOS VERSION : BIOS version

  EC VERSION : EC version

  Build Date : BIOS Build Date

- Processor : Processor Type / Processor Speed
- Manufacturer : Manufacturer Name
- Product Name : Product Name

■ 4.2.2 Main Menu



- System Date

  This item allows you to set the system date. The date format is [day:month:date:year].

  Use [ENTER], [TAB] or [SHIFT-TAB] to select a field.

- System Time

  This item allows you to set the system time. The system clock will go on no matter you shut down the PC or get into sleep mode. The time format is [hour:minute:second].

  Use [+] or [-] to configure system Time.

Day	Day of the week, from Sun to Sat, which is determined by BIOS (read-only).
Month (Month)	The month from 01 (January) to 12 (December).
Date (Date)	The date from 01 to 31.
Year (Year)	The year can be adjusted by users.

- Memory Information

  This item provides the information about the system memory.

- Total Memory

  This allows you to see the total amount of memory.

■ 4.2.3 Advanced Menu


Aptio Setup Utility – Copyright (C) 2011 American Megatrends, Inc.
Info Main Advanced Security Boot Exit
Advanced Settings
Execute Disable Bit [Enabled]
SATA Mode Selection [AHCI]
Serial ATA Port 0 Empty
Serial ATA Port 1 Empty
Trusted Computing
XD can prevent certain classes of malicious buffer overflow attacks when combined with a supporting OS (Windows Server 2003 SP1, Windows XP SP2, SuSE Linux 9.2, RedHat Enterprise 3 Update 3.)
→←: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
ESC: Exit
Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.

- Execute-Disable Bit

  When disabled, force the XD feature flag to always return 0.

- SATA Mode Selection

  SATA AHCI mode or IDE mode select.

- Serial ATA Port 0/1

  While entering setup,BIOS auto detects the presence of AHCI devices. This displays the status of auto detection of AHCI devices.

- Trusted Computing

  Turn TPM Enable/Disable. NOTE: Your Computer will reboot during restart in order to change State of TPM.

■ 4.2.4 Security Menu



・ Change Administrator Password

When this item is selected, a message box shall appear on the screen as below:

Enter New Password

Type a maximum of 20-digit password and press [Enter].

The password typed now will replace any previously set password from CMOS memory. You may also press [ESC] to abandon new password setting.

Select Change User Password to give or to abandon password setting same as Change Administrator Password item above.

Note that Administrator Password field allows users to enter and change the settings of the BIOS SETUP UTILITY, while User Password field only allows users to enter the BIOS SETUP UTILITY without having the authorization to make any change.

The Password Check item is used to specify the type of BIOS password protection that is implemented.

To clear a set Administrator Password/ User Password, just press [Enter] under Change Administrator Password/ Change User Password field when you are prompted to enter the password. A message box will pop up confirming password will be disabled. Once the password is disabled, the system will boot and user can enter setup without entering password.

■ 4.2.5 Boot Menu


Aptio Setup Utility – Copyright (C) 2011 American Megatrends, Inc.
Info Main Advanced Security Boot Exit
Boot Configuration
LAN Remote Boot [Disabled]
Set Boot Priority
1st Boot [USB KEY]
2nd Boot [Hard Disk]
3rd Boot [Network]
4th Boot [CD/DVD]
5th Boot [USB Hard Disk]
6th Boot [USB CD/DVD]
7th Boot [USB Floppy]
8th Boot [UEFI: Generic USB Flash Disk 0.00]
USB KEY Drive BBS Priorities
UEFI Boot Drive BBS Priorities
Enables/Disables LAN Remote Boot option
→←: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
ESC: Exit
Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.

- Boot Configuration

  Configure Settings during System Boot.

- LAN Remote Boot:

  Boot from LAN or not.

- Set Boot Priority (1st/2nd/3rd/..... Boot)

  Specifies the boot sequence from the available devices.
  A device enclosed in parenthesis has been disabled in the corresponding type menu.

- USB KEY Drive / UEFI Boot Drive BBS Priorities

  Specifies the Boot Device Priority sequence.

■ 4.2.6 Exit Menu


Aptio Setup Utility – Copyright (C) 2011 American Megatrends, Inc.
Info Main Advanced Security Boot Exit
Save & Exit Options
Save Changes and Exit
Discard Changes and Exit
Discard Changes
Restore Defaults
Exit system setup after saving the changes.
→←: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
ESC: Exit
Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.

- Save Changes and Exit

  Exit system setup after saving the changes.
  F4 key can be used for this operation.

- Discard Changes and Exit

  Exit system setup without saving any changes.
  ESC key can be used for this operation.

- Discard Changes

  Discards changes done so far to any of the setup questions.
  F2 key can be used for this operation.

- Restore Defaults

  Restore/Load Defaults values for all the setup options.
  F3 key can be used for this operation.